



..... EBW 8340 Printer Installation Instructions

- 1.) Read the printer manual for correct ribbon, paper and power supply installation instructions.
- 2.) The printer DIP switches have been preset at the factory. If it becomes necessary to change the switch settings, please do so with the printer power turned ***OFF***. The DIP switches should be set as follows:

DSW #1	1	2	3	4	5	6	7	8
	ON	ON	ON	ON	ON	ON	ON	ON

- 3.) Plug DB25 ribbon cable into the parallel connector of the User Interface Board, and install the other end into the cutout in the bottom left of cabinet with supplied hardware.
- 4.) Plug one end of the Parallel cable into the rear of the printer.
- 5.) Plug the other end of the Parallel cable into the installed port of the EBW AutoStik cabinet.
- 6.) Turn on the power to the printer.
- 7.) Program the console as necessary.

NOTES: Any time the printer DIP switches are changed, it must be done with the printer power off.

[7.11] Program Which Panel Printer Menu

CONFIGURE → WHICH PANEL PRINTER: will be displayed

1) Press [EDIT] to enter menu

2) Enter the printer type

INCREMENT KEY: Increments which panel printer as follows:

| NONE |

| SEIKO PANEL PRINTER |

| PANASONIC PANEL PRINTER Plain |

| PANASONIC PANEL PRINTER w/HiLight |

| TELPAR PANEL PRINTER |

DEFAULT KEY: Resets panel printer to

| PANASONIC PANEL PRINTER Plain |.

Verify which panel printer reflects printer installed in Auto/Stik Controller!

3) Press [ENTER] to accept.

4) Press [NEXT] to continue.

Programming Tip: Panel Printer and Log Printer may not be enabled at the same time.
--

[7.12] Program Which Log Printer Menu

FUNCTIONALITY:

An IBM compatible printer can be attached to the printer port located on the user interface module.

CONFIGURE → WHICH LOG PRINTER: will be displayed

1) Press [EDIT] to enter menu

2) Enter log printer type

[INCREMENT] key: Increments which log printer between

| NONE / LOG PRINTER |

[DEFAULT] key: Resets which log printer to | NONE |.

Verify log printer installation and programming is correct!

3) Press [ENTER] to accept.

4) Press [NEXT] to continue.