ESCO Orchidea PAS-6001

PUMP ACCESS SYSTEM CONTROLLER INSTALLATION GUIDE

Version 1.7.7



Orchidea PAS-6001 Table of Contents

- Orchidea Quick Installation Guide
- System Architecture
- OrchIdea Interconnection Diagram
- Connecting Pump Current Loop Wires
- CL-Box Board Current Loop LED Indicators
- Connecting Vx510 to Ruby & CL-Boxes
- VX510 COM Connections
- Connecting to Tank Monitor BIR Module for Reconciliation
- Cascading CL-Box with Gilbarco D-Box
- CL-Box Board
- Online VX510 Display
- VX510 Function Key Usage

Orchidea Quick Installation Guide

FOLLOW THESE STEPS IN ORDER WHEN INSTALLING THE ORCHIDEA PAS-6001

CL-BOX INSTALLATION


- 1. Install the CL-Box, VX510 & Power Supplies. Do Not apply Power or connect COM cables yet
- 2. Set **ALL Pump Switches** to the **OFF** position
- 3. Connect the **Pump CL Wires** to the **Positive** & **Negative Terminals** in the **CL-Box**
- 4. Connect all **CRIND CL Wires** to the **Gilbarco D-Box** following standard procedures
- 5. Apply Power to the CL-Box & verify The Red Power & Blue Loop LEDs are lit
- 6. Set each Connected Pump Switch to ON one at a time & verify that the Blue LED remains lit
- 7. Make sure all **Unused Pump Switches** are **OFF** or the **CL Link** will be broken & the **Blue LED** will go out
- 8. If turning any Connected Pump Switch ON causes the Blue LED to go OUT check the CL wiring to that pump
- 9. If the **CL** connection appears to be good try wiring it to a different position in the **CL-Box**
- 10. If the problem can not be corrected leave that pump **Isolated** until it is resolved
- 11. Set all **Pump Switches** back to the **OFF** position & verify that the **Blue LED** remains lit

VX510 INSTALLATION & STARTUP


- 1. Connect the Tripp-Lite **DRS232 Surge Suppressor** to the **Fuel COM** cable coming from the **POS**
- 2. Cable Color code: Blue-Straight, Green RTO-VX510 RS-232, Black-Ruby COM
- 3. The VX510 COM cables are all pinned differently & CAN NOT be interchanged. FOLLOW COLOR CODE!!!
- 4. Connect the **Straight cable** from the **Vx510 PINPAD Port** to the **Pump CL-Box**
- 5. Connect RTO cable from the Vx510 RS232 Port to the Fuel COM cable via the Surge Suppressor
- 6. Connect **DCR COM** cable to the **Gilbarco D-Box** via the **DCR Converter** following standard procedures
- 7. Apply **Power** to the **VX510** Terminal & verify the display reads "**WAITING FOR GRADES**"
- 8. The Yellow RX LED in the Pump CL-Box should start Blinking within a few seconds
- 9. Set each **Connected** pump switch to **ON** one at a time & verify that the **Blue Loop LED** remains lit
- 10. Perform a full **FUEL** & **DCR Initialization** from the **Ruby** to initialize the **Orchidea**
- 11. Verify that the Green TX LEDs & the Yellow RX LEDs are Blinking indicating good CL-Box COM
- 12. Verify that the **VX510** display reads "**IDLE**" for valid fueling points & "**CLOSED**" for those not valid
- 13. Verify that all **Fueling Points** & **CRINDs** are functioning normally
- 14. The status of the **Fueling Points** & current **Sale** can be observed on the **VX510** display

System Architecture

Integrated with Ruby / Sapphire



Orchidea Interconnection Diagram



References


→ Green side of Ruby to Omni (RTO) cable goes to RS232 Port on VX510


→ Black side of RTO cable goes through Surge Suppressor to Ruby Fuel Cable

→ Blue Straight cable goes from Pump CL-Box to Pin Pad Port on VX510

Standard Pump & CRIND CL Wiring goes to Pump & CRIND CL-Boxes


Connecting Pump Current Loop Wires





Note: All unused Current Loop positions must be switched OFF!!!

CL-Box Current Loop LED Indicators



Blue: Current Loop continuity indicator (must be lit for 2-wire COM)


RED: Power indicator (should always be on)

GREEN: TX (Flashing indicates least one pump is responding)

YELLOW: RX (system is communicating to the pump loop)

Note: All unused Current Loop positions must be switched OFF!!!

Connecting Vx510 to Ruby & CL-Box




Note: All VX510 COM cables are pinned differently & CAN NOT be interchanged!!!

VX510 COM Connections




Green end of RUBY-OMNI (RTO) Cable goes to RS232 Port Blue Straight
Through Cable
goes to PIN Pad
Port


Connecting To Tank Monitor BIR Module for Reconciliation




Cascading CL-Box with Gilbarco D-Box



CL-Box Board



Online Vx510 Display



Vx510 Function Keys Usage



Press F1 to cycle between screens

Press F3 to Print Configuration Parameters

Press F4 to Print Current Pump Totals